




QUICK START GUIDE

SIZE



SPECIFICATIONS

Material: Silicone+ABS
Weights: 0.18lb
Functions: 10 Vibrating Modes
Remote Control


Charging Time: 90min
Using Time: 55min
Waterproof: IPX6

FUNCTION



Product

Long press "  " for 3s to turn on/off the device.
Short press "  " to change the 10 vibration modes.




Remote control

Long press "  " for 3s to pause or continue.
Short press "  " to change the 10 vibration modes.

USB CHARGING

***WARNING: Please DO NOT use adaptor with ">5V" output**



- Ensure the device is fully charged before first use.
- Connect the device to a USB port to charge.
- Do not use the device while charging.
- Use a power adaptor with output below 5V.
- Do not submerge in water for extended periods.

PRODUCT CLEANING

- Clean: Wash the product with warm water and antibacterial soap.
- Wipe: Dry the product with paper towels.
- Save: Keep the product in a cool, dry, and clean place.
- Attention: Never clean the product with organic cleaners that contain alcohol, gasoline, or acetone. Avoid exposure to direct sunlight.

SAFETY

- Do not use the product at temperatures over 167 °F (75 °C).
- Stop using it immediately if you experience any discomfort.
- Water-based lubricant is recommended.
- Do not use the product if you find it rough or damaged.
- Keep out of reach of children.



Certificates



MADE IN CHINA