

# JYBIS

## QUICK START GUIDE

### SIZE



### SPECIFICATION

Materials: Silicone+ABS  
Power Source: Rechargeable  
Weights: 0.6 lb  
Special Features: 7 Vibrating Modes  
10 Rotating Modes  
7 Suction Modes

Run time: 60 Minutes  
Recharging: 150 Minutes  
Waterproof: IPX6

### FUNCTION



Vibrating button

Long press "🌀" for 2s to turn on/off.

Short press "🌀" to change 7 vibrating modes.

Sucking button

Long press "🔌" for 2s to turn on/off.

Short press "🔌" to change 7 sucking modes.

Rotating button


Long press "🌀" for 2s to turn on/off.

Short press "🌀" to change 10 rotating modes.

## USB CHARGING

**\*WARNING: Please do NOT use an adapter with an output greater than 5V.**

**\*Make sure to fully charge the toy before the first use.**



## PRODUCT CLEANING

- Clean: Please wash product with toy cleaner or antibacterial soap and water.
- Dry: Pat or wipe dry with clean cloth or towel.
- Store: Keep toy in a cool, dry place.
- Attention: Never clean the toy with abrasive cleaners containing alcohol, gasoline or acetone. Avoid direct sunlight.

## SAFETY

- Do not use it at temperature over 167°F/75 °C.
- Stop using the toy if any discomfort occurs.
- Use with a water-based lubricant.
- Do not use if the product is damaged.
- Keep out of reach of children.



Certificates



MADE IN CHINA