

JOYBIS

QUICK START GUIDE

SIZE



SPECIFICATION

Materials:	Silicone+ABS	Run time:	110 Minutes
Power Source:	Rechargeable	Recharging:	around 120 Minutes
Weights:	0.77 lb	Waterproof:	IPX5
Special Features:	6 Tongue Licking & Vibrating Modes 6 Auto Sucking Modes Adjustable Suction Intensity		

FUNCTION




- Release air: Short press "⊙" to release air.
- Auto suction: Short press "⏸" to change 6 auto suction modes.
- Manual suction: Short press "⏸" to start sucking. Short press "⏸" again to stop.
- Power button: Long press "⏻" for 3s to turn on/off the toy.
- Short press "⏻" to adjust 6 tongue vibration & licking modes.

USB CHARGING

***WARNING: Please DO NOT use adaptor with ">5V" output**

***Please make sure your toy is fully charged the first time**



PRODUCT CLEANING

- Clean: Please wash product with toy cleaner or antibacterial soap and water.
- Dry: Pat or wipe dry with clean cloth or towel.
- Store: Keep toy in a cool, dry place.
- Attention: Never clean the toy with abrasive cleaners containing alcohol, gasoline or acetone. Avoid direct sunlight.

SAFETY

- Do not use it at temperature over 167°F/75 °C.
- Stop using the toy if any discomfort occurs.
- Use with a water-based lubricant.
- Do not use if the product is damaged.
- Keep out of reach of children.



MADE IN CHINA