


JOYBIS

QUICK START GUIDE


SIZE



SPECIFICATION

Product Name:	Medusa Massager
Product Size:	144.5 * 102.5 * 48.0 mm
Material:	Silicone + TPE
Function Mode:	10 Tongue-like licking modes; 10 Tapping & Vibrating modes
Voice rating:	≤ 60dB
Rated voltage:	3.7V
Rated current:	500mA
Shelf life:	3 years
Suitable for people:	18 years old and above

FUNCTION



On / Off / Vibration key

Long press the "V" key to turn on the machine, the indicator light is always on, the machine shakes a little, the product enters standby mode. Click "V" again to start the vibration function, click to switch the frequency, 3 + 7 frequency cycle conversion, double-click to pause the vibration function, long press the power button to turn off the machine.

Shake the key


Standby state, click "A" rocking key, start the vibration function, again "A" click to switch the frequency, a total of 3 + 7-frequency cycle conversion, double-click to pause the function.

USB CHARGING

*WARNING: Please DO NOT use adaptor with $>5V$ output



Magnetic charging



- Connect the device to USB port to charge .
- Do not use the device while charging.
- Please connect with power adapter below 5V.
- Do not submerge under water.
- If the product is not charging while plugged in, please wait 10 minutes and try again.

PRODUCT CLEANING

- Clean: Please wash product with toy cleaner or antibacterial soap and water.
- Dry: Pat or wipe dry with clean cloth or towel.
- Store: Keep toy in a cool, dry place.
- Attention: Never clean the toy with abrasive cleaners containing alcohol, gasoline or acetone.
Avoid direct sunlight.

SAFETY

As a close companion of the majority of users, to be able to safely and healthily use this massager is the user and our common responsibility.

We would like to remind you that this product is only suitable for adults over 18 years of age, please keep it away from children. Please do not use excessive force during use, please pay attention to avoid injury. Do not mix this product with others. If you feel unwell during use, stop using the product immediately. Regularly check the product for damage and stop using it immediately if damage is found. This product should be treated as waste electrical and electronic products and recycled to the appropriate waste electrical and electronic products recycling station.

DISCLAIMERS

- Declare that this manual is only for product use tutorials, all interpretation rights belong to the company.
- Please use this product carefully, any party of any abuse use of this product our company shall not take any responsibility



MADE IN CHINA