




QUICK START GUIDE

SIZE




SPECIFICATIONS

Material: Silicone+ABS
Noise: $\leq 65\text{dB}$
Product Size: 10.2*2.68*2.68in
Functions: 10 Vibrating modes
3 thrusting modes

Charging Time: 240min
Using Time: 40min
Waterproof: IPX7

FUNCTION



FUNCTION

Long press "⏻" to turn on the device. The indicator light will illuminate, and the device will enter standby mode.


Short press "⏻" to activate the thrusting function. Short press "⏻" again to change 3 thrusting modes.

Short press "🌀" to activate the vibrating function. Short press "🌀" again to change 10 vibrating modes.

Long press "⏻" to stop all functions and turn off the device.

USB CHARGING

***WARNING: Please DO NOT use adaptor with ">5V" output**



- Connect the device to USB port to charge.
- Do not use the device while charging.
- Please connect with power adaptor below 5V.
- Do not submerge under water.
- If the product is not charging while plugged in, please wait 10 minutes and try again.

PRODUCT CLEANING

- Clean: Please clean product with warm water or antibacterial soap.
- Wipe: Dry the product with paper towels.
- Save: Keep the product in a cool, dry and clean place.
- Attention: Never clean this product with organic cleaner that contains alcohol, gasoline or acetone. Avoid direct sunshine.

SAFETY

- Do not use it at temperature over 167 °F/75 °C.
- Stop using it when any discomfort occurs.
- It is recommended to use it with water-based lubricant.
- Do not use it if you find the product unsmooth or damaged.
- Keep out of reach of children.



Certificates



MADE IN CHINA