


JOYBIS

QUICK START GUIDE

SIZE



SPECIFICATION

Product Name:	G-spot Vibrator	Material:	Silicone+ABS
Battery:	650mAh lithium ion	Product Size:	126 * 102 * 31 mm
Motor:	2	Input:	5V 1A
Mode:	10 Tapping & Vibrating modes; 10 Tongue-like Licking &Vibrating Modes	Noise:	Less than 50db
Using time:	45-60mins	Charging Time:	120mins

FUNCTION



Product

Long press  for 2 seconds to turn on/off the product.

Short press  to change the vibrating modes.

Short press  to change the tapping & tongue-like licking modes.



Remote control


Short press to change 10 vibrating modes.

Short press to change 10 tapping & tongue-like licking modes.

Long press to turn off the product.

USB CHARGING

***WARNING: Please DO NOT use adaptor with ">5V" output**



- Connect the device to USB port to charge .
- Do not use the device while charging.
- Please connect with power adapter below 5V.
- Do not submerge under water.
- If the product is not charging while plugged in, please wait 10 minutes and try again.

PRODUCT CLEANING

- Clean: Please wash product with toy cleaner or antibacterial soap and water.
- Dry: Pat or wipe dry with clean cloth or towel.
- Store: Keep toy in a cool, dry place.
- Attention: Never clean the toy with abrasive cleaners containing alcohol, gasoline or acetone. Avoid direct sunlight.

SAFETY

- Do not use it at temperature over 167°F/75 °C.
- Stop using the toy if any discomfort occurs.
- Use with a water-based lubricant.
- Do not use if the product is damaged.
- Keep out of reach of children.



Certificates



MADE IN CHINA