


QUICK START GUIDE



12.40 in (315 mm)

*Before using, suggest to use your palm/leg to feel the suction and get use to the button function

Waterproof:

SPECIFICATIONS

Material: Weights: Product Size: Functions:

Silicone+ABS+TPE 1.48 lb

9 Vibrating Modes 3 Suction Modes 3 Suction Intensities Charging Time: Using Time: 30~60min

IPX6

FUNCTION





- ON/OFF: Hold on " Tor 3 seconds
- Press "
 " to switch vibrating







- SWITCH MODES:
 Press**
 "to suck, press again to stop. Once again to recycle but weaker (Strong → Normal → Weak,





• Press "(1)" to switch 3 modes suction

Caution:

Follow the tips if the suction is too strong

- 1. Hold "O" for 3s to stop suction, it will release gradually.
 2. Hold "O" for 3s to turn off the product, it will release gradully
- 3. Twist off the handle and cylinder directly!

HOW TO INSTALL










- 1. Screw the base into the transparent cylinder tightly;
- 2. Put the silicone sleeve on the cylinder to start.

(Note: If no feeling of suction, please double check STEP 1

USB MAGNETIC CHARGING

*WARNING: Please DO NOT use adaptor with ">5V" output *Please make sure your toy is fully charged while the first time



- · Connect the device to USB port to charge
- · Do not use the device while charging.
- · Please connect with power adapter below 5V.
- · Do not submerge under water
- . If the product does not charge when plugged in, please wait for 10 minutes to confirm.

PRODUCT CLEANING

- Please clean product with warm water or antibacterial soap.
- Dry the product with paper towels.
- Keep the product in a cool, dry and clean place.
- . Attention: Never clean this product with organic cleaner that contains alcohol, gasoline or acetone. Avoid direct sunshine.

- Do not use it at temperature over 167 °F/75 °C.
- It is recommended to use it with water-based lubricant.
- . Do not use it if you find the product unsmooth or damaged.
- . Keep out of reach of children.

SAFETY











