


SIZE





Specification

Materials: Silicone+ABS


Power: USB Magnetic Charging

Size: 5 87*4 57*1 42in

Function: 10 vibrating modes; 3 thrusting & swelling modes Packaging includes vibrator, manual, charging cable.

Waterproof rating: IPX6
Charging time: 120 minutes
Usage time: 45 minutes
Rated Current: 500mA
Rated voltage: ≨5.0V

FUNCTION



Product

Long press ② for 2 seconds to turn on the device. The LED light will illuminate, indicating the device is in standby mode. Short press ③ to change 3 modes: thrusting and swelling. To turn off the device, long press ② for 2 seconds. Short press ④ to change 10 vibrating modes.

To turn off the vibration mode, long press ⑥ for 2 seconds.


Remote control:

Once the device is in standby mode, short press \bigodot to change 10 vibrating modes.

Short press (1) to change the 3 thrusting and swelling modes. Long press (1) to turn off the device.

USB CHARGING

*WARNING: Please DO NOT use adaptor with ">5V" output



- Connect the device to USB port to charge.
- Do not use the device while charging.
- Please connect with power adapter below 5V.
- Do not submerge under water.
- If the product is not charging while plugged in, please wait 10 minutes and trv again.

PRODUCT INTRODUCTION

The massager is a stretchable expansion + vibration massager for women, it not only has vibration as well as thrusting and swelling function, multi-frequency conversion, massage to stimulate private parts, so that women have a feeling of heartbeat and fullness, enjoy the pleasure, bring the real pleasure of orgasm, it is also a good choice to wear it when aoina out.

Equipped with a 10-meter long-distance remote control, enjoy yourself anytime, anywhere,

CLEAN AND HYGIENIC

- Thoroughly clean the soft gel before and after each use.
- 2. When cleaning, it can be scrubbed with warm water and deodorized soap. It is recommended to disinfect with special disinfectant.
 - or 75% alcohol (it is not recommended to use alcohol for a long time because alcohol will corrode surface of the
- 3. Dry:after washing, it is recommended to wipe with a dry cotton cloth
- or high-quality paper towels is also a good choice. Wipe dry and then air dry to avoid exposure to the sun.
- 4. Store the product in a clean environment and separate it from other materials.

CAUTIONS

- 1. Disinfect the product before and after each use, wash it with warm water and sterilized soap and dry it with a clean velvet.
- 2. It is forbidden to use massage oil, hand cream, detergent, gasoline or acetone as lubricant.
- 3. Please do not use the fast charging power supply, otherwise it will cause poor charging!
- 4. This product is partially waterproof and cannot be directly washed or soak in water

SAFFTY REMINDER

As a close companion of users, it is our responsibility to remind you to use this product safely and healthily.

- 1. The product is a personal product, for your health, please do not share with other people to use it.
- 2. If you see any surface damage before using this product, please stop using it immediately.
- 3. If you feel uncomfortable during use, please stop using it immediately. Warning: This product is only suitable for adults over 18 years of age









