

JOYBIS

QUICK START GUIDE

SIZE



SPECIFICATION

Materials:	Silicone+ABS	Product Size:	8.4 x 1.6in
Power Source:	Rechargeable	Run time:	60 Minutes
Weights:	0.82 lb	Recharging:	90 Minutes
Special Features:	3 Speeds & 7 Vibrating Modes Water Spray Modes	Waterproof:	Life Waterproof

FUNCTION



Product On/Off Button:

Long press "⏻" for 2 seconds, and the indicator light will stay on, indicating that the device is in standby mode.
Short press "⏻" again to start the vibration function, which has 3 speeds and 7 modes.
Double-press the button to turn the water-spray function on/off.
Long press "⏻" for 2 seconds to turn off the device.



Remote Control:

Shutdown Button:


When the product is working, long press "▲" for 2 seconds to turn it off.

Vibration Button:

Short press "▼" to start the vibration when the power is on. It has 3 speeds and 7 modes.
Long press "▼" for 2 seconds to turn the water-spray function on, and Long press "▼" for 2 seconds again to stop the spray.

USB CHARGING

***WARNING: Please DO NOT use adaptor with ">5V" output**



PRODUCT CLEANING

- **Cleaning:** Wash the dildo with warm water and mild soap, then rinse it with hot water (up to 50°C). Be careful to avoid getting water into the switch and charging port during cleaning. Use your fingers to wash and knead the product, avoiding brushes or harsh, acidic cleaners.
- **Wiping:** After washing, wipe the product with a lint-free cloth or towel to dry.
- **Maintenance:** Always turn off the power after use to avoid potential damage to the product or power supply. Store the product in a flannelette or dust bag, and keep it in a cool, dry place.

SAFETY

- Please do not place the product in any location where heat cannot dissipate.
- This is a personal hygiene item, so do not share it to avoid bacterial infection.
- Although the product has many functions, please avoid overusing it, as excessive use may reduce sensitivity.
- It is recommended to use the product with a condom and professional lubricating fluid for optimal experience.
- Please stop using the product immediately if you feel unwell or if it becomes damaged.
- Do not substitute professional lubricating fluid with massage oils, skin creams, gasoline, acetone, or other chemicals.
- Clean the product immediately after use and store it properly to avoid bacterial infection.
- After cleaning and maintenance, store the product in a cool, dry, and private place. If not in use for a long time, recharge it before reuse to prevent battery depletion. For battery-powered products, please remove the batteries before storage.



Certificates



MADE IN CHINA