


JOYBIS

QUICK START GUIDE


SIZE



SPECIFICATION

Materials:	Silicone+ABS	Run time:	55 Minutes
Power Source:	Rechargeable	Recharging:	120 Minutes
Weights:	0.71 lb	Waterproof:	Life waterproof
Special Features:	10 Tongue-licking & vibrating modes 2 Sucking modes		

FUNCTION








Turn On / 10 Licking Modes

1. Long press "⏻" for 2-3 seconds to turn on the product, entering standby mode.
2. Short press "⏻" to change 10 licking modes and long press "⏻" to stop the function.

Two Automatic Suction Modes

1. In standby mode, short press "⏻" to start the suction function. The product will automatically cycle between inspiratory and exhaust air.
2. Short press "⏻" to switch between 2 suction modes. Long press "⏻" to stop the function.

Manual Suction Mode / Release Air



1. In standby mode, long press " " to activate manual suction mode. Release " " to stop it.
2. If the inspiratory force is not strong enough in automatic suction mode, long press " " for the most powerful suction. Release " " to stop.
3. Short press " " to release the air when in automatic suction mode state.

After using, long press " " again to turn off the product.

USB CHARGING

***WARNING: Please DO NOT use adaptor with ">5V" output**

***Please make sure your toy is fully charged the first time**



PRODUCT CLEANING

- Clean: Please wash product with toy cleaner or antibacterial soap and water.
- Dry: Pat or wipe dry with clean cloth or towel.
- Store: Keep toy in a cool, dry place.
- Attention: Never clean the toy with abrasive cleaners containing alcohol, gasoline or acetone. Avoid direct sunlight.

SAFETY

- Do not use it at temperature over 167°F/75 °C.
- Stop using the toy if any discomfort occurs.
- Use with a water-based lubricant.
- Do not use if the product is damaged.
- Keep out of reach of children.



MADE IN CHINA