

# JYBIS

## QUICK START GUIDE

### SIZE



### PRODUCT PARAMETERS:

Materials: Silicone+ABS+PC

360° tongue shaking modes: 5

Tongue vibrating modes: 5

Accessories: 1\*USB charging cable,1\*manual

Sucking modes: 4

Rate voltage: 3.7V

Charger: 5V /1A ,2A

### FUNCTION



Long press "🔄" for 2 seconds to turn on/off the device.

Short press "🔄" shortly to change 5 tongue-like licking and vibrating modes.


Short press "👄" shortly to change 4 sucking modes.

Long press "👄" for 2 seconds to turn off the sucking function.

Short press "🔄" and "👄" simultaneously to pause all functions.

## USB CHARGING

**\*WARNING: Please DO NOT use adaptor with ">5V" output**



- Make sure to fully charge the toy before the first use.
- The indicator light blinks while charging and stays on when fully charged.

## PRODUCT CLEANING

- Clean: Wash the product with warm water and antibacterial soap.
- Wipe: Dry the product with paper towels.
- Store: Keep the product in a cool, dry, and clean place.
- Attention: Do not clean with organic cleaners containing alcohol, gasoline, or acetone. Avoid direct sunlight.

## SAFETY

- Do not use it at temperatures exceeding 167°F (75°C).
- Stop using if any discomfort occurs.
- Water-based lubricant is recommended.
- Do not use if the product is damaged or feels unsmooth.
- Keep out of reach of children.



MADE IN CHINA